

# SWEDX

Your Digital Signage Partner

## User's Guide

SS-28K1

SS-32K1

SS-40K1

SS-43K1

SS-45K1

SS-50K1

SS-58K1

SS-60K1

SS-65K1

SS-75K1

SM-28K1

SM-32K1

SM-40K1

SM-43K1

SM-45K1

SM-50K1

SM-58K1

SM-60K1

SM-65K1





SWEDX Matrix Video Walls



SWEDX Direct



SWEDX Lamina



Digital Signage Screens

SWEDX offers a wide range of LED-TVs and digital signage products and its accessories. For more information please visit [www.swedx.com](http://www.swedx.com)




SWEDX V

## Lamina Accessories




Digital Signage Player  
(Windows/Android)



Front/Back Shelf



Flightcase




Top Banner



Side Shelf



Protection Ring



Mobile base with  
lockable wheels

| INDEX                        | Page |
|------------------------------|------|
| Introduction                 | 4    |
| Safety precaution            | 4    |
| Basic operation              | 5    |
| Contents                     | 6    |
| Inputs                       | 6    |
| Remote Control (FR4)         | 7    |
| Remote Control Buttons (FR4) | 8    |
| Remote Control Buttons (FR)  | 9    |
| Main Operations              | 10   |
| Volume Control               | 10   |
| OSD Menu Operations          | 10   |
| OSD Menu Structure:          | 10   |
| First Time Installation      | 11   |
| Menu > Channel (ATV)         | 12   |
| Menu > Picture Menu          | 13   |
| Menu > Sound Menu            | 14   |
| Menu > Time Menu             | 15   |
| Menu > Settings Menu         | 16   |
| USB Media Player             | 17   |
| Supported Formats and Codecs | 18   |
| Troubleshooting              | 20   |
| Warranty and Service         | 21   |
| How to get service           | 22   |
| Limitation of liability      | 22   |

## Introduction

Thank you for choosing SWEDX products. Please read this manual thoroughly before operating the product. Make sure the display was not damaged in transit. Should the product be damaged, please contact your dealer and do not install it. Check that you have all the accessories according to the model.

## Safety precaution

- Do not place the product on unstable places, from which it may fall off
- Do not expose the product to extreme temperature and humid environment
- Avoid subjecting the product to direct sunlight or other heat sources
- Do not put the product into any liquid
- Do not put anything inside the product, or place water container on top of the it
- In thunder rainy days (especially with lightning), please unplug the power and antenna cables
- Do not step on the power cable, or tangle them together
- Avoid overload of the exterior electric outlet to prevent fire hazard of electric shock
- Clean the product with dry and soft fabric
- If your product is broken, do not repair it by yourself, but contact the maintenance personnel
- If the remote control is left unused for a longtime, please take the batteries out and store them in dry places
- Avoid dropping the remote control
- If the product is installed for exhibition purpose, please do not place the overheated part on the ground or carpet to prevent accident
- The apparatus shall not be exposed to dripping or splashing and that no object filled with liquids, such as vases, shall be placed on the apparatus
- Where the MAINS plug or an appliance coupler is used as a disconnect device, the disconnect device shall remain readily operable
- Battery shall not be exposed to excessive heat such as sunshine, fire or the like
- Excessive sound pressure from earphones and headphone can cause hearing loss

Please install the product at proper position, such as wall or ceiling. Please install it under the guidance of professional staff.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference

2. This device must accept any interference received, including interference that may cause undesired operation

Please disconnect the power cord if this equipment will not be used for a long time.

## Precautions When Displaying a Still Image

A still image may cause permanent damage to the screen

- Do not display a still image on the screen for more than 2 hours as it can cause screen image retention. This image retention is also known as "screen burn". To avoid such image retention, reduce the degree of brightness and contrast of the screen when displaying a still image
- Watching the screen in 4:3 format for a long period of time may leave traces of borders displayed on the left, right and center of the screen caused by the difference of light emission on the screen. Playing a DVD or a game console may cause a similar effect to the screen. Damages caused by the above effect are not covered by the Warranty.
- Displaying still images from Video games and PC for longer than a certain period of time may produce partial after-images. To prevent this effect, reduce the 'brightness' and 'contrast' when displaying still images



### WARNING

**To prevent the spread of fire, keep candles or other open flames away from this product at all times**

### Basic operation

- Use AC 100-240V 50~60 Hz power outlet for the product power supply
- If the screen of the product is not on, please press the power button on the remote control or on the product
- If you want to shut off the product temporary, please press the power button on the remote control or on the product
- If you want to shut off the product completely, please disconnect the power cable
- In **Component** and **AV** modes the product will **shut off** if there is no signal input for **30 minutes**
- In **PC-RGB** and **HDMI** modes the product will enter **idle** state if there is no signal input after **30 seconds**
- In **Media Player 1/2** modes the product will remain **On** if there is no signal input
- The setting and tuning of picture and sound will be saved when the product is shut off, which will be working in the pre-shut off state when the product is turned on again
- If PC signal source is used, please first set the resolution of the PC display card as the following modes:  
For HDMI 1/2/3 (3840x2160 @ 60Hz)  
For PC (1920 x 1080 @ 60Hz)
- If there is progressive output of the signal used by the user, signal source with progressive output is recommended

### Preparation

- Put the product on a stable surface
- Do not fix the product with others fixations than those provided or suggested by the manufacturer
- If you have a wall mount, check that it is steady.
- Do not place any material on the product.
- Do not block or cover the ventilation openings on the product
- The product must be plugged with a tension source of 110-240 volts and 50~60 Hz
- Power cord and cables must be properly routed and protected to prevent from stepping on them
- Keep the power cord away from any heat source. Possible fire hazard


### Heating sources and humidity

- Keep the product dry and away from humidity
- Keep the product away from heat sources
- Cleaning and maintenance
- Unplug the product before cleaning it. Do not use solvents or liquids to clean the product
- Only clean the product with a soft and dry fabric
- In case of troubleshooting, do not use spare parts other than those suggested by the manufacturer. Using inadequate spare parts can lead to electric shocks, short-circuits fire

or others incidents. Please contact a technical authorized by SWEDX

### Departure in holidays

- Unplug the product during lightning storms or when unused for long periods of time



### WARNING:

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE

## Contents

Included items:



2 x AAA Battery



Notice



AC Cable



Remote Control



LED Screen

### CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type



AAA Battery

### CAUTION

The batteries shall not be exposed to excessive heat such as sunshine, fire or the like



AAA Battery

## Inputs

### 1. PC

Input for PC (VGA) sources

### 2. PC AUDIO

Input for PC audio when PC (Personal Computer) is connected

### 3. COMPONENT

Input for Component (YPBPR) sources.  
Supports maximum resolution 1080p @ 60 Hz

*\*Component/YPBPR and AV shares the same audio input*

### 4. AV

Input for AV (Audio/Video) sources

### 5. On/OFF

Key to power the product On/Off

### 6. Remote Pairing

Key to pair the remote control with the product

### 7. POWER INPUT

Input for 100-240 V power 50~60Hz

### 8. ATV

Input for analog TV channels

### 9. MEDIA PLAYER 1

Input for USB Media Player 1/Firmware upgrade

### 10. MEDIA PLAYER 2

Input for USB Media Player 2

### 11. HDMI1

Input for HDMI1 (Ver. 2.0). Supports maximum resolution 3840x2160 @ 60 Hz

### 12. HDMI2


Input for HDMI2 (Ver. 2.0). Supports maximum resolution 3840x2160 @ 60 Hz

### 13. HDMI3

Input for HDMI3 (Ver. 2.0). Supports maximum resolution 3840x2160 @ 60 Hz

### 14. COAXIAL

Output for digital audio signal (Coaxial)



## Remote Control (FR4)

The remote control is based on both 2.4 GHz and Infrared.

The remote control is equipped with LED indicators. The **RED** indicator states that the remote is in **Infrared** mode and the **BLUE** indicator is for **2.4 GHz** mode. Recent products from SWEDX uses 2.4 GHz receivers.

The 2.4 GHz technology allows the remote to control the TV without targeting it because the receiver is built inside the the TV. Each SWEDX TV has a pre-configured remote control meaning that if you have several SWEDX TVs then the remote control for one of the TVs will function only with that particular TV and not with the other TVs.

To switch between Infrared and 2.4 GHz mode press and hold the



buttons for 5 seconds. The Red LED will flash 3 times and switch from the current mode to the other one.

To pair the remote with the TV follow the steps below

1. Connect the product (e.g screen) to power outlet
2. Make sure that the remote is in 2.4 GHz mode
3. Press and hold the



buttons on the remote control simultaneously for about 5 seconds. The BLUE LED will flash 5 times indicating that the remote is now paired with the TV.

Recent 2.4 GHz based products from SWEDX are equipped with a pairing key in order to avoid pairing more than one product when more than one SWEDX products is close by. A On/Off key is also available in recent SWEDX products.

If your product is equipped with pairing key please press and hold the pairing key for 2 second when the Blue LED light is flashing after pressing




On/Off Key  
Pairing Key



## Remote control buttons (FR4)

This remote control model is included in all models except SS28K1 and SM28K1 models

1. On/Off button
2. Shortcut to HDMI1,2,3
3. Number buttons for direct channel access
4. Display additional information
5. Volume increase
6. Volume decrease
7. Picture freeze
8. RED
9. GREEN
10. *Not applicable for this product*
11. Navigation button UP
12. Navigation/adjust button LEFT
13. Navigation button DOWN
14. Menu display. In OSD sub-menu press to access previous menu
15. *Not applicable for this product*
16. Shortcut to Media Player 1,2
17. Aspect Ratio toggling
18. Start/Pause play
19. Stop play
20. Fast backward
21. Previous Title
22. *Not applicable for this product*
23. Mute the built-in speakers
24. Available sources selection
25. *Not applicable for this product*
26. *Not applicable for this product*
27. *Not applicable for this product*
28. *Not applicable for this product*
29. Enter sleep mode in certain chosen time
30. Blue
31. Yellow
32. *Not applicable for this product*
33. *Not applicable for this product*
34. Confirm/activate button
35. Navigation/adjust button RIGHT
36. Exit the OSD
37. *Not applicable for this product*
38. Shortcut to AV
39. *Not applicable for this product*
40. Fast forward
41. Next Title
42. *Not applicable for this product*






## Remote control (FR) buttons

This remote control model is included in SS28K1 and SM28K1 models

- |   |  |
|---|--|
| 1. On/Off button  | 27. <i>Not applicable for this product</i> |
| 2. Mute the built-in speakers                                   | 28. LED indicator                          |
| 3. Enter sleep mode in certain chosen time                      | 29. Available sources selection            |
| 4. <i>Not applicable for this product</i>                       | 30. Display additional information         |
| 5. Aspect Ratio toggling  | 31. Picture freeze                         |
| 6. Number buttons for direct channel access                     | 32. Alter sound mode                       |
| 7. <i>Not applicable for this product</i>                       | 33. Alter picture mode                     |
| 8. Shortcut to HDMI 1,2,3                                       | 34. Volume increase                        |
| 9. Shortcut to PC input   | 35. Volume decrease                        |
| 10. Menu display. In OSD sub-menu press to access previous menu | 36. <i>Not applicable for this product</i> |
| 11. Navigation button UP  | 37. <i>Not applicable for this product</i> |
| 12. Confirm/activate button                                     | 38. <i>Not applicable for this product</i> |
| 13. Navigation/adjust button LEFT                               | 39. <i>Not applicable for this product</i> |
| 14. Navigation button DOWN                                      | 40. Exit the OSD                           |
| 15. Shortcut to Component                                       | 41. Navigation/adjust button RIGHT         |
| 16. Stop play   | 42. <i>Not applicable for this product</i> |
| 17. Start/Pause play  | 43. <i>Not applicable for this product</i> |
| 18. Fast forward  | 44. <i>Not applicable for this product</i> |
| 19. Fast backward   | 45. Next Title                             |
| 20. RED   | 46. Previous Title                         |
| 21. GREEN   | 47. Blue                                   |
| 22. <i>Not applicable for this product</i>                      | 48. Yellow                                 |
| 23. <i>Not applicable for this product</i>                      | 49. <i>Not applicable for this product</i> |
| 24. <i>Not applicable for this product</i>                      | 50. <i>Not applicable for this product</i> |
| 25. <i>Not applicable for this product</i>                      | 51. <i>Not applicable for this product</i> |
| 26. <i>Not applicable for this product</i>                      | 52. <i>Not applicable for this product</i> |



## Main Operations

### Turning On And Off




The product turns on automatically when it is connected to power. When the product is in Stand-by mode press **POWER** on the remote control or the On/Off button on the control buttons. The product will turn on and will be ready to be used.

### Select Source

**SOURCE**



Press **SOURCE** on the remote control. The source list menu will appear. Navigate the list with **Up/Down** on the remote control to select the source and confirm by pressing **OK**.



## Volume Control



Press **VOL+ / VOL-** on the remote control to adjust the volume level.



Press the **MUTE** on the remote control to mute the sound.



## OSD Menu Operation



- Press **MENU** on the remote control to access the OSD Menu. Pressing the same button again will move you backward in the OSD structure.
- Press **OK** button to confirm/select.
- Use **LEFT & RIGHT** buttons to navigate or change the parameters of the current sub-menu.

- Use **UP & DOWN** buttons to navigate in the OSD Menu.
- Press **EXIT** button to exit the OSD Menu.



## OSD Menu Structure

- OSD (On Screen Display) allows users to control or adjust various features and settings in accordance with desired preferences.
- Press the **MENU** button on the remote control to see the main OSD menu.



### OSD Menu Operation:

- Main Menu:** Press **MENU** on the remote control to enter the main OSD menu. First, choose Main menu item you need with the buttons **◀ & ▶**. To select a Main menu items, just press **OK**.
- Sub Menu:** Each menu item has its own sub menu items to set.
- Sub Menu items:**
  - A: If there is no value to adjust it means there is a sub menu which you can access by pressing **OK** and modify the menu values.
  - B: If there is no **▶** part, the item has adjustable values. Use **◀ & ▶** to adjust the values.
  - C: If the sub-menu item is grey colored, it means this item is not available in the particular mode.



**First Time Installation**

The first time the TV is turned on an installation

| First Time Installation |           |
|-------------------------|-----------|
| OSD Language            | English   |
| Energy Mode             | Home Mode |


guide will be presented. Chose the desired OSD language.

In the energy mode you can choose between Home and Dynamic mode. The home mode will reduce the back light intensity in order to save energy while the Dynamic mode will increase the back light intensity to the maximum.

This Menu is available in the following models only

- SS-28K1
- SS-40K1
- SS-49K1
- SS-50K1
- SS-58K1
- ME-65K1

Menu > Channel (ATV)



This Menu is available in the following models only  
SS-28K1  
SS-40K1  
SS-49K1  
SS-50K1  
SS-58K1  
ME-65K1


In this Menu you can search for TV-channels manually or automatically, manage the TV channels such as deleting, adding to favorites, skipping and locking. You can also use the PVR function which allows to record or time shift TV-programs

The TV model of this product is equipped with the following Tuners

Analog TV Tuner, supports Pal and Secam

Auto Tuning


Use the Auto Tuning menu to search for TV-channels. The found channels will be saved in



the channel lists.


To access the channel list, press Channel List button on the remote.

ATV Manual Tuning




You can perform a manual channel search for analog channels (ATV). You can choose the channel you want to save to and also use Fine Tune to adjust the tuning for the channel to get better picture. You can also change the **Sound system** (BG, DK, I, L, L') for the channel

Programme Edit



In this menu you can:  
Delete a channel (*press Red button*)  
Rename a channel (*press Yellow button*)  
Skip a channel (*press Blue button*)  
Add a channel to favorites list (*press FAV button*)

## Menu > Picture



Use the Picture menu to adjust the picture settings to meet your requirements:

### Picture mode

**Standard:** Suitable for a normal room

**Mild:** Suitable for a dark room

**User:** In User mode you can adjust the Contrast, Brightness, Color, Sharpness to meet your requirements

**Dynamic:** Suitable for a bright room

### Color Temperature

Choose between predefined settings User, Warm, Medium and Cold). In User mode you can adjust the Red, Green and Blue color temperature.

### Aspect Ratio

Set the various picture options such as picture size and aspect ratio.

*Depending on the input source, the picture size options may vary.*

*The connected device to the controller may have its own set of screen sizes as well. However, it is highly recommended to use PointToPoint / Just Scan mode.*

#### Auto

Automatically adjusts the picture size to the signal

#### Zoom1&2

Magnifies the picture size.

#### 4:3

Sets the picture to basic (4:3) mode.

*Do not watch in 4:3 format for a long time. Traces of borders displayed on the left, right and center of the screen may cause image retention (screen burn) which are not covered by the warranty.*

#### PointToPoint

Displays the signal without any cut-off when HDMI (720p / 1080i / 1080p / 2160p) signals. The PointToPoint mode will display without scaling which means if the signal resolution is lower than 3840x2160 then the picture will be shown according to its original size.

#### Just Scan

Just Scan mode will display crispier picture with

scaling to fill the entire screen.

### Noise Reduction/MPEG Noise Reduction

Choose to activate noise reduction. Available options are Off, Low, Middle and High.

*If the signal received by the input controller is weak, you can activate the Noise Reduction feature to help reduce any static and ghosting that may appear on the screen.*

### Screen (only in PC mode)

When the TV is in PC-Mode additional settings are available for PC-Setup.


H-Offset: Adjust the PC's screen positioning horizontally

V-Offset: Adjust the PC's screen positioning vertically

Size: Adjust the screen size

Phase: Adjust the signal phase

## Menu > Sound



Use the Sound menu to adjust the sound settings to meet desired requirements:

### **Sound Mode**

Choose between predefined settings:

**Standard:** Suitable for normal programs

**Music:** Suitable for music program

**Movie:** Suitable for movies

**Sports:** Suitable for sport programs

**User:** In User mode you can adjust the Treble and Bass to meet desired requirements.

### **Balance**

Adjust the sound output balance between left and right speaker.

### **Auto Volume**

Each broadcasting station has its own signal conditions, and so it is not easy to adjust the volume every time the channel is changed. This feature lets you automatically adjust the volume of the desired channel by lowering the sound output when the modulation signal is high or by raising the sound output when the modulation signal is low.


### **Surround Sound**

In TrueSurround or SRS TrueSurround mode the screen delivers a compelling, virtual surround sound experience through the internal television speakers. It is fully compatible with all multichannel formats.

### **SPDIF Mode**

Choose the output mode for the SPDIF signal. Choose between Auto or PCM.

## Menu > Time



### Clock

Use the Time menu to set the date and time for the product. The date and time are important for usage of the timer function.

Set the date and time under the Clock option by choosing the clock option and pressing the ► button. Change the values to the correct time by pressing the ◀ & ► buttons. Press Menu to exit and save the new date and time settings.

### Off Time

Set a certain time to turn **off** the TV automatically. The available time intervals are **Once, Everyday, Mon-Fri, Mon-Sat, Mon-Sun** and **Sunday**.

### On Time

Set a certain time to turn **On** the TV automatically. The available time intervals are **Once, Everyday, Mon-Fri, Mon-Sat, Mon-Sun** and **Sunday**.

***When the Time On function is activated you can choose the following parameters***

***Source: Which source to be activated when the LED-TV turns on***

***Volume: Audio volume level when the LED-TV turns on***


### Sleep Timer

Set the TV to turn off after a certain time. The time intervals are **240, 180, 120, 90, 60, 30, 20** and **10 min.**

### Auto Sleep

When set to ON the TV will turn off automatically if no input signal is detected otherwise the TV will remain ON even if no input signal is detected.

## Menu > OPTION



### **OSD Language:**

Choose the OSD language. Available languages are English, Deutsch, Spanish, French, Italian, German, Japanese, Swedish, Arabic, Simplified Chinese.

### **Restore Factory Default**

This function will restore the product to the factory defaults and will erase any customized settings.

### **Color Range**

Choose the scope of the color range. Available options are Auto, 0~255 and 16~255.

### **EDID Mode**

Products with support for HDMI 2.0 are recommended to take full advantage of the 4K feature in Swedx product by setting the EDID Mode to EDID 2.0. Available options are Auto, EDID 1.4 and EDID 2.0.

### **No Signal Screen**


Change the background color of the display when no signal is detected. Available options are black or blue.

### **MEMC (Motion Estimation/Motion Compensation)**

Enhancement to compensate the difference between the screens refresh rate and signal frame rate. Active for smoother motion and deactivate for shorter input lag.



## USB Media Player



This product is equipped with high end USB Media Player. It is capable of playing music, movies (up to 1080p and with subtitle support), and display photos or text documents.

To Enter USB mode

*Press Source*

*Choose USB*

*Press Enter*

In USB mode you can choose between:

**Photos:** Enables you to display several formats of photos and images

**Music:** Enables you to play several formats of music and audio files

**Movie:** Enables you to play several formats of movies and video files

**Text:** Enables you to display TXT files

### Remote Control Keys used in USB Mode

The INFO button will display available controllers where it is possible to i.e. rotate an image. The controllers may vary depending on the USB mode.

Navigation Key to navigate in the different position of the menu and press enter to activate the function.

The AUDIO button will alter audio track (if several audio tracks are available in the played file).

The SUB-T button will alter the subtitles or turn it off (if several subtitles languages are available in the played file).

The subtitle file should be saved in UNICODE In order to display the correct characters.

## Functions



Repeat the file



Go to defined time position in the file



Repeat the file. Choose between ALWAYS, ONCE or NO REPEAT



Play audio files while displaying images



Display the Playlist



Display current file's information



Press to rotate 90 degrees CW



Press to rotate 90 degrees CW



Press to Zoom IN



Press to Zoom OUT



Press to MOVE in ZOOM mode



Define a part of a video to be repeated



Change aspect ratio



Play step forward in a video



Play slowly forward in a video

## Supported Formats and Codecs

|         | Format         | Video Codec   | Audio Codec                         | Resolution | Frame Rate       | Mbit/s   |  |
|---------|----------------|---|-------------------------------------|------------|------------------|----------|--|
| Video   | AVI            | MJPEG   | MP3, WMA, AAC, MP2, PCM             | 640x480    | 23,976~30≤16Mbps | ≤ 10Mbps |  |
|         |                | DIVX.311/DIVX4/DIVX5  |                                     | 720x576    |                  | ≤ 10Mbps |  |
|         |                | XVID/MPEG-2/MPEG4/H.264                                       |                                     | 1920x1080  |                  | ≤ 20Mbps |  |
|         | MP4            | MPEG-2/MPEG-4/H.264   |                                     |            |                  | ≤ 40Mbps |  |
|         | TS             | MPEG-2  |                                     |            |                  |          |  |
|         | TRP            |   |                                     |            |                  | ≤ 20Mbps |  |
|         | MPG            | MPEG-1/MPEG-2   |                                     |            |                  |          |  |
|         | NOV            | MPEG-4/H.264  |                                     |            |                  |          |  |
|         | MKV            |   |                                     |            |                  |          |  |
|         | DAT            | MPEG1   | MP2                                 | 352X288    | ≤ 16Mbps         |          |  |
| VOB     | MPEG2          | 720x576   |                                     |            |                  |          |  |
| Format  | Max resolution | Colors  |                                     |            |                  |          |  |
| Picture | BMP            | 1000 x 1000 pixels  | 16, 256, 16 bit, 24 bit och 32 bit. |            |                  |          |  |
|         | JPEG           | 3840x2160 / <b>Recommended resolution is 3840x2160 pixels</b> |                                     |            |                  |          |  |
|         | PNG            | 1000x1000 pixels  |                                     |            |                  |          |  |
| Audio   | MP3            | 8K-48K. 32K+320K  |                                     |            |                  |          |  |
|         | WAV            | 32K-48KHz 32K-320Kbps   |                                     |            |                  |          |  |
|         | M4A, AAC       | 16K-48K. 32K+192K   |                                     |            |                  |          |  |

### Information:

The Media Player inputs supports:

USB Flash Drive and Hard disks are supported. Supported formatting formats are, NTFS, FAT32, FAT16. NTFS Compressed is not supported.

**The files must be saved in the root folder. Folder structure is not supported.**

Max 5000 files.



## **Troubleshooting**

Before contacting SWEDX service or your dealer, perform the following simple checks. If you cannot solve the problem using the instructions below, note the model and serial number of your product and contact your local dealer

### **No sound or picture**

- Check that the mains lead has been connected to a wall socket
- Check the picture contrast and brightness settings
- Check the volume

### **Normal picture but no sound**

- Check the volume
- Check whether the MUTE button has been pressed on the remote control

### **No picture or black and white picture**

- Adjust the color settings
- Check that the broadcast system selected is correct

### **Sound and picture interference**

- Try to identify the electrical appliance that is affecting the set and move it further away.
- Plug your set into a different mains socket

### **Blurred or snowy picture, distorted sound**

- Check the direction, location and connections of your aerial
- This interference is often due to the use of an indoor aerial

### **Remote control malfunctions**

- Ensure that the remote is in correct mode
- Replace the remote control batteries
- Clean the upper edge of the remote control (transmission window)
- Check the battery terminals
- Turn off the product and unplug the AC cable from the wall socket and then plug the AC cable and turn on the product

### **“No signal” message is displayed**

- Check that the signal cable is firmly connected to the source input
- Check that the source is turned on

### **On PC mode, “Not Supported Mode” message is displayed**

- Check the maximum resolution and the frequency of the video adapter. For HD models the recommended resolution is 1366x768 and for Full HD models the recommended resolution is 1920x1080 (for PC mode). In HDMI mode the

recommended resolution is  
3840x2160@60Hz

### **The image is too light or too dark**

- Adjust the Brightness and Contrast

### **Pixel Mapping**

- It is recommended to choose aspect ratio PointToPoint or JUST SCAN to achieve pixel mapping in HDMI modes

### **The screen does not accept 4K 60Hz**

- Change the EDID Mode in Option menu to EDID 2.0

## **Warranty and Service**

The following terms apply only to new "in the original carton" SWEDX products marketed and distributed by SWEDX, which are purchased and used by the original consumer purchaser.

Depending on the model, your terms and conditions may be different from those shown below, and this information is subject to change without prior notice. Unless specifically stated otherwise, used and reconditioned products that are resold have no warranty from SWEDX and are considered sold "AS-IS", however, the selling dealer may offer additional service options.

### **Warranty for SWEDX products:**

The warranty period is 12 months from purchase date.

When the products are used commercially the warranty period is 3 months

### **What the warranty covers:**

SWEDX warrants your SWEDX display(s) against defects in material and workmanship during the warranty period from SWEDX factory delivery date shown in the shipping documents. If a product proves to be defective in material or workmanship during the warranty period, SWEDX will, at its sole option repair or replace the product with a similar product, provided the purchaser adheres to certain return authorization procedures and guidelines. SWEDX reserves the right to charge customer in case of warranty conditions not are fulfilled.

### **Who the warranty protects:**

This warranty is valid only for the first purchaser.

### **What the warranty does not cover:**

1. Any product which the serial number has been defaced, modified or removed.
2. Damage, deterioration or malfunction resulting from:
  - A. Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
  - B. Repair or attempted repair by anyone not authorized by SWEDX.
  - C. Any damage of the product due to shipment.
  - D. Removal or installation of the product.
  - E. Causes external to the product, such as electric power fluctuations or failure.
  - F. Use of supplies or parts not meeting SWEDX specifications.
  - G. Normal wear and tear.
  - H. Any other cause which does not relate to a product defect.

3. Cosmetic damage by purchaser, such as markings, discoloration, scratches, dents, anti-theft devices markings, gouges or any other defacement.
4. Physically damaged products by purchaser, such as broken PCB, Housing, damaged LCD Module.
5. No Defect Found (product returned to SWEDX as defective but failure is not duplicated by SWEDX's test method.)
6. The product is not in accordance with the fault in the application
7. Timber is a lifelike natural material which can cause some little changes in the precision of the produced product such as small openings line beside the connecting point and some other small changes which are out of SWEDX control and don't make any effect for the product functionality.

### **Dead on Arrival (DOA)**

If the product fails within the manufacturer's DOA period, a replacement product will be offered.

### **Before contacting us:**

In many cases, your product may not need repair. Before you contact us, please consult the troubleshooting section in your user's manual or SWEDX's FAQ web pages at <http://www.swedx.com> to see if you can easily remedy the problem yourself.

**How to get service:**

For information on obtaining warranty service, contact SWEDX dealer (the place where you bought your product) in first choice. If for any reason you can not contact your dealer, please contact SWEDX Customer Service by visiting <http://www.swedx.com>.

**SWEDX technical support services:**

During the period of product warranty, we support your basic configuration, setup and troubleshooting questions, and when required, we provide you with all instructions on how to return your product for repair. For support inquiries, please visit <http://www.swedx.com>.

SWEDX reserves the right to make final decisions regarding problem determination and the appropriate service option. Exchange units assume the remaining warranty of the original product. Please refer to your SWEDX Limited Warranty Statement for complete terms and conditions, as some models have other terms and conditions. Some limitations and restrictions apply and these programs are subject to change without prior notice.

**Limitation of liability**

If your SWEDX product fails to work as warranted above, your sole and exclusive remedy shall be repaired or replaced. SWEDX's maximum liability under this limited warranty is expressly limited to the lesser of the price you have paid for the product or the cost of repairing or replacement of any hardware components that malfunction in conditions of normal use. SWEDX is not liable for any damages caused by the product or the failure of the product to perform, including any lost profits or savings or special, incidental, or consequential damages. SWEDX is not liable for any claim made by a third party or made by you for a third party.

This limitation of liability applies whether damages are sought, or a claim made, under this limited warranty or as a tort claim (including negligence and strict product liability), a contract claim, or any other claim. This limitation of liability cannot be waived or amended by any person. This limitation of liability will be effective even if you have advised SWEDX.



# SWEDX

Your Digital Signage Partner

Other products from SWEDX



[www.swedx.com](http://www.swedx.com)

